2 of 193

PROPERTY OF ORDER LINE 127

Wen 23 1 C 152 Mar 78

KY-685 #193 Cy3

PROCESS AND EFFLUENT CONTROL OF FLUORINE AND FLUORIDE GASES IN THE CONVERSION OF URANIUM ORES TO URANIUM HEXAFLUORIDE BY GAS CHROMATOGRAPHY,

KENNETH W. CARPENTER

PREPARED FOR ORAL PRESENTATION AT THE CANADIAN CHROMATOGRAPHY CONFERENCE IN MONTREAL, CANADA. APRIL 27–28, 1978

UNION CARBIDE

PADUCAH GASEOUS DIFFUSION PLANT

prepared for the U.S. DEPARTMENT OF ENERGY under U.S. GOVERNMENT Contract W-7405 eng 26

Oup. 793

# APPROVAL FOR RELEASE

Document: #	KY685	; Date	<b>2/28/78</b> ;
Title/Subject_		D EFFLUENT	
ELUORINE C	AND FLUORIDE GAS	ES IN THE C	ONVERSION OF
Approval for 1	inrestricted release of this	document is authorized	orized by the Oak
	Site Classification and In		
Marietta Energ	y Systems, Inc., PO Box 20	)03, Oak Ridge, T	N 3783/1-7307.
Aru	n Stuis	L (103)	1/29/93
K-25 Classific	ation & Information Contro	ol Officer	Date

#193

#### NOTICE

THIS REPORT WAS PREPARED AS AN ACCOUNT OF WORK SPONSORED BY AN AGENCY OF THE UNITED STATES GOVERN—MENT NOR ANY AGENCY THEREOF, NOR ANY OF THEIR EMPLOYEE, NOR ANY OF THEIR CONTRACTORS, SUB—CONTRACTORS, OR THEIR EMPLOYEES, MAKES ANY WARRANTY, EXPRESS OR IMPLIED, NOR ASSUMES ANY LEGAL LIABILITY OR RESPONSIBILITY FOR ANY THIRD PARTY'S USE OF THE RESULTS OF SUCH USE OF ANY INFORMATION, APPARATUS, PRODUCT OR PROCESS DISCLOSED IN THIS REPORT, NOR REPRESENTS THAT ITS USE BY SUCH THIRD PARTY WOULD NOT INFRINGE PRIVATELY OWNED RIGHTS.

By acceptance of this article, the publisher and/or recipient acknowledges the U.S. Government's right to retain a nonexclusive royalty-free license in and to any copyright covering this paper.

Reference to a company or product name does not imply approval or recommendation of the product by Union Carbide Corporation or the U.S. Energy Research and Development Administration to the exclusion of others that may meet specifications.

Printed in the United States of America Available from National Technical Information Service U. S. Department of Commerce 5285 Port Royal Road Springfield, VA 22161 Price: Printed Copy \$4.50 Microfiche \$3.00 Date of Issue: February 28, 1978

Report Number: KY-685

Subject Category: Chemistry, UC-4

PROCESS AND EFFLUENT CONTROL OF FLUORINE AND FLUORIDE GASES
IN THE
CONVERSION OF URANIUM ORES TO URANIUM HEXAFLUORIDE BY GAS CHROMATOGRAPHY

Kenneth W. Carpenter

UNION CARBIDE CORPORATION NUCLEAR DIVISION

Paducah Gaseous Diffusion Plant Paducah, Kentucky

Prepared for the Department of Energy under U.S. Government Contract W-7405 eng 26

#### Abstract

Process and Effluent Control of F<sub>2</sub> and Fluoride Gases in the Conversion of Uranium Ores to Uranium Hexafluoride by Gas Chromatography, Carpenter, K. W., Union Carbide Corp., Nuclear Division, Paducah, Ky. A brief description of the process and equipment involved in the conversion of UO3 to UF6 at the Paducah Gaseous Diffusion Feed Plant is given. This plant is a part of the uranium isotope enrichment complex operated by the Union Carbide Corp., Nuclear Division for the U.S. Department of Energy. The applications of specially designed corrosive gas chromatographs in analyzing and controlling critical stages in the process are described. Information is presented on the design and construction of the chromatographs. Special features include unique methods of simultaneously determining PPM concentrations of UF  $_{6}$  and % levels of F<sub>2</sub> and air components in a minimum time, and determining O2, N2, F2, and HF concentrations in a single analysis. A description of specially coated teflon columns, selective sample component converters, and selective trapping systems used to resolve very difficult problems usually associated with the analyses of corrosive gases such as  $F_2$ , HF, and UF<sub>6</sub> is presented.

# CONTENTS

	Page
SUMMARY	. 4
INTRODUCTION	. 5
Description of the Uranium Hexafluoride Feed Plant, Paducah, Ky	. 6
Identification of Process Monitoring and Control Points	. 7
Description of Chromatograph Used to Measure Air Components and Othe Impurities in a Fluorine Gas Stream	r . 8
Description of Teledyne UV Photometric Analyzer for Measuring Fluoring Uranium Hexafluoride	ne • 9
Description of Chromatograph Used to Measure Uranium Hexafluoride and Fluorine	đ • 9
Preparation of Teflon Columns for Corrosive Gas Chromatography	. 9
Table 1, Fluorination Plant Vent Stack Analyses	. 11
Table 2, Performance Data for Teflon Column	. 12
No. 1 Corrosive Gas Chromatograph Flow Scheme, Figure 4	. 16
Gas Density Detector, Figure 5	. 17
Chromatograph No. 1 Scans of Fluorine Samples	. 18
No. 2 Corrosive Gas Chromatograph Flow Scheme, Figure 9	. 21
No. 2 Corrosive Gas Chromatograph Sample Scans, Figure 10	. 22
REFERENCES	. 24
BIBLIOGRAPHY	. 25
ACKNOWLEDGEMENTS	. 26

#### SUMMARY

The development of chromatographic instrumentation for the analyses of corrosive (halogenated) gases has evolved over a period of twenty or more years in the Union Carbide Corporation. Many of the techniques developed in the laboratories have been successfully implemented in field applications. By using the chromatographs, time consuming wet chemical analyses have been eliminated. Adapting the chromatographs to field service has made the analytical results immediately available to the process operators. Thus process control and efficiency has been improved and fluoride emissions to the environment have been reduced.

#### INTRODUCTION

The Paducah Gaseous Diffusion Plant (PGDP) is operated by the Union Carbide Corporation, Nuclear Division (UCC-ND) under government contract for the U. S. Department of Energy (US-DOE). The purpose of the plant complex is to enrich the isotopic concentration of  $^{235}\text{U}$  found in uranium ores and reprocessed uranium materials. The  $^{235}\text{U}$  is enriched from a level of approximately normal (0.7%  $^{235}\text{U}$ ) to slightly enriched material (2 - 3%  $^{235}\text{U}$ ). The slightly enriched material is subsequently used at other facilities to prepare fuel elements for nuclear power reactors.

In the process of deriving isotopically enriched uranium from normal uranium, many chemical and physical processes are involved. Great demands are placed on analytical instruments to provide proper control over these processes. This paper briefly describes one step in uranium's long journey from the earth to electrical service for man and some of the analytical devices used in directing the course of the journey are discussed.

Feed uranium materials which are to be enriched must first be converted to the gas uranium hexafluoride (UF<sub>6</sub>) before it is introduced into the enrichment cascade. At the Paducah Feed Plant, this conversion is accomplished in several discrete stages (Figure 1, Figure 2, and Slide 1). First ammonia (NH<sub>3</sub>) is cracked to provide a source of hydrogen ( $H_2$ ).

2 NH<sub>3</sub> 
$$\longrightarrow$$
 N<sub>2</sub> + 3H<sub>2</sub> Reaction 1  $\triangle$ 

In the second step, uranium trioxide  $(\mathrm{UO}_3)$  is reduced to uranium dioxide  $(\mathrm{UO}_2)$  in fluid bed reactors using the cracked ammonia.

$$UO_3$$
 +  $H_2$   $UO_2$  +  $H_2O$   $\Delta H = -23.89$  K Cal/Mol U (s)  $\Delta$  (v) (yellow powder) (brown powder)

Reaction 2

In the third step, the water vapor is vented and the solid uranium dioxide is hydrofluorinated to uranium tetrafluoride (UF $_4$ ) in ribbon-screw reactors.

Reaction 3

As UF $_4$  is formed, it can immediately be transferred for further processing to UF $_6$  or it can be stored and held for processing at a later date.

In the fourth step, elemental fluorine  $(F_2)$  is produced by the electrolysis of a molten salt, potassium meta-bifluoride  $(KF \cdot 2HF)$ .

2 KF · 
$$H_2F_3$$
 1- - 2e<sup>-</sup>  $\xrightarrow{6000 \text{ amperes}}$  2 KF · 2HF +  $F_2$  ↑ carbon anode 10 VDC

Reaction 4

2 KF · 
$$H_3F_2$$
 <sup>1+</sup> - 2e<sup>-</sup>  $\xrightarrow{6000 \text{ amperes}}$  2 KF · 2HF +  $H_2$  ↑ steel cathode (g) 10 VDC

Reaction 5

The cells operate at  $180-200^\circ$  F and the product is fluorine containing 6-8 mole % HF, 1 mole % air, and < 0.1 mole % CF<sub>4</sub>. Prior to transfer to the UF<sub>4</sub> - UF<sub>6</sub> reactors, the HF is recovered from the fluorine by cold trapping at -90° F. The fluorine reaching the reactors typically contains 96 mole % F<sub>2</sub>, 3 mole % HF, 1 mole % air, and < 0.1 mole % CF<sub>4</sub>.

The final stage in the conversion of uranium oxides to uranium hexafluoride occurs in the fluorination flame tower reactors. Here the green salt, uranium tetrafluoride (UF $_4$ ) is reacted with elemental fluorine (F $_2$ ) to form uranium hexafluoride (UF $_6$ ) (Figure 3, Slide 2).

$$UF_4 + F_2 \xrightarrow{2200^{\circ}F} UF_6 + F_2 \qquad \Delta H = -60.05 \text{ K Cal/Mol U}$$
(g) (g) (g) (g)
(green salt) (excess) (excess)

Reaction 6

An excess of  $F_2$  is fed to the reaction so that the product gas is UF<sub>6</sub> containing 10 mole %  $F_2$ . The UF<sub>6</sub> is stripped from the gas stream in an ammonia/glycol sublimation cold trap (10-20°F). The off-gas from this system passes to a clean-up reactor (CUR) which reacts the residual fluorine with an excess of solid uranium tetrafluoride to form uranium hexafluoride.

Reaction 7

Final extraction of the uranium hexafluoride from the process gas stream is made in an ammonia/carbon dioxide sublimation cold trap (-40°F). The off-gas from this system contains less than 2 mole %  $F_2$  and less than 0.05 mole %  $UF_6$ . This gas stream then passes through a fluid bed absorber (FBA) which strips the residual  $F_2$  and  $UF_6$  from the gas stream before venting to the atmosphere.

$$UF_4 + \frac{1}{2}F_2$$
  $UF_5$   $OH = 40.95 \text{ K Cal/Mol}$  (g) (excess)

Reaction 8

$$UF_4 + xUF_6$$
  $UF_4 \cdot xUF_6$   $UF_4 \cdot xUF_6$   $UF_4 \cdot xUF_6$   $UF_4 \cdot xUF_6$   $UF_4 \cdot xUF_6$ 

Reaction 9

The UF  $_6$  is typically less than 50 PPM molar and the  $\text{F}_2$  is less than 1 mole % in the vent gas from the fluorination system.

The analytical instrumentation described in this paper is used to monitor and control the fluorination process and fluoride emissions from the fluorination system. Monitoring and control is conducted at four points in the process (Figure 3, Slide 2).

(1) The fluorine fed to the fluorination tower reactors is monitored using a gas chromatograph. This instrument analyzes and records the concentrations of  $F_2$ ,  $O_2$ ,  $N_2$ ,  $CF_4$ , and HF. The  $F_2$  concentration determines the operating conditions necessary for efficient fluorination reactions. Tower reaction rate control is accomplished by varying feed rates of  $UF_4$  and  $F_2$ . This monitoring station allows system inleakage or significant process failure in the fluorine plant to be detected at an early stage.

- (2) The concentration of excess fluorine in the product UF $_6$  (fluorination tower reactor outlet) is carefully monitored by an UV photometric analyzer. At this point, the excess F $_2$  must not be less than 4 mole % or the fluorination reaction will be compromised and the towers will plug. The excess F $_2$  must not be greater than 10 mole % or the fluid bed absorber will pass fluorides to the environment. The photometric analyzer provides real time analyses of the fluorination reaction and very efficient control is maintained in this stage of the process.
- (3) The third monitoring and control point is located immediately downstream of the FBA. A gas chromatograph monitors the vent gas from the FBA for concentrations of  $F_2$  and  $UF_6$ .
- (4) The fourth and final monitoring and control point is the "Total Vent Flow Control Station". Monitoring the vent flow is a differential pressure transmitter reading the pressure drop across a calibrated flow orifice. A continuous read-out of the vent flow and pressure is recorded on a strip chart recorder in the central control room. Vent flow and chromatographic records provide an accurate and continuous record of the amounts of fluorides and uranium materials emitted to the environment from the feed plant.

The chromatographs used in feed plant service are basically modeled after those developed by C. W. Weber, et. al., ORGDP, Oak Ridge, Tennessee, and Rosmassler, Mayo, and Harris, (1) PGDP, Paducah, Kentucky. The basic units have been modified to suit the specific needs in the feed plant.

The first chromatograph in the system (control point no. 1) samples the  $F_2$  header supplying  $F_2$  to the fluorination tower reactors. This chromatographic system uses a split column arrangement with a single gas density detector, (Figure 4, Slide 3). The sample loop and injection system is formed using two Whitey Multi-Port Ball Valves (Model 43Y Series), interconnecting tubing, and a Whitey 90° Spring Return Air Operator (Model MS-133SR). All wettable portions of the sampling system are either teflon, nickel or monel. Sampling and analyses are automatic using an ATC timer-programer. Argon is used as the carrier and reference gases because we desire to measure  $O_2$  and  $N_2$  in the process fluorine. Immediately after the sample is swept from the loop, the carrier gas stream splits with one-tenth the total flow directed through a capillary restrictor passing to a NaBr converter and then into a 1/4" O.D. x 20' teflon column. The  $F_2$  in the sample is converted to  $Br_2$  in the NaBr converter. The teflon column then separates the components of air,  $Br_2$ , HF,  $CF_4$ , etc.

The conversion of  $F_2$  to  $Br_2$  is necessitated by the fact that  $O_2$  and  $F_2$  are not resolved (separated) by the teflon columns used for corrosive gas chromatography. In a sample containing both  $O_2$  and  $F_2$ , the two compounds would elute from the column simultaneously and the analyses for either would be biased by the presence of the other. Converting the  $F_2$  to  $Br_2$  before the sample reaches the column allows the  $O_2$  to be separated from the  $Br_2$ . An indirect measurement for  $F_2$  concentration is thus made. Either NaBr or NaCl can be used successfully. NaBr is preferred due to the increased sensitivity of  $Br_2$  over  $Cl_2$  when using a gas density detector.

The balance (nine-tenths) of the carrier flow is directed into a NaF trap and charcoal converter. The NaF trap strips the HF from the sample and the charcoal converts the  $F_2$  to  $CF_4$ . Thus neither HF or  $F_2$  is allowed to pass to the mole sieves column which would be destroyed by either of these materials. The sample sweeps from the converter into a 1/4" 0.D. x 6' 5A mole sieves column which resolves the components of  $0_2$  and  $N_2$ . At  $120^\circ F$ the CF4 is permanently absorbed on the charcoal or mole sieves. After elution from the columns, the two carrier gas streams recombine before entering the Gow-Mac gas density detector (Figure 4, Slide 6). The argon carrier gas stream, sweeping the sample components into the detector sequentially, is compared electronically with the reference side of the gas density detector. The sensing elements of the detector are formed by a matched pair of ohmic thermistors rated at 9,000 ohms each. The design of the gas density detector is such that the thermistors are never exposed to the corrosive halogenated sample. Each thermistor element is incorporated in opposing branches of a wheatstone bridge circuit. The detector senses any difference in the densities of the reference and carrier gas streams as an imbalance in the wheatstone bridge circuitry. This imbalance is amplified and recorded as shown on Figure 5, Slide 4. A sample chromatogram is shown in Figure 6, Slide 5. The effluent from the chromatographic system is cleaned of fluorides in a solid sorbent chemical trap before being vented to the atmosphere.

The second monitoring and control point in the system (control point no. 2) utilizes a Teledyne UV Photometric Analyzer, Series 600 to analyze the concentration of excess  $F_2$  at the outlet of the fluorination tower reactors. This is an unique application of a UV analyzer in that spectral absorbance in the measuring region (347 nM) due to UF<sub>6</sub> is electronically substracted by reference to a region of absorbance specifically due to UF<sub>6</sub> (407 nM). As  $F_2$  absorbs at the 347 nM region but not at the 407 nM region, the instrument can thus sense  $F_2$  in the presence of varying concentrations of UF<sub>6</sub> (Figure 7, Figure 8, and Slide 6). Information from this analyzer is also used to control the feed rates of reactants to the fluorination tower reactors.

The second chromatograph in the system samples the outlet of the FBA (control point no. 3). Information from this instrument is used to adjust the feed rates of UF<sub>4</sub> to both the CUR and the FBA. A single line diagram of the chromatographic system is shown in Figure 9, Slide 7. An air carrier gas is used to sweep a measured volume of sample gas from the sample loop into the system of NaF-NaBr trap and converter and into the chromatograph columns.

The columns used are made by coating 40-60 mesh teflon, Johns Mansville 6H Molding Powder, with a halocarbon oil (Hooker Chemical Co., Type FS-5). The oil is applied by dispersion in Freon-113 solvent with subsequent vacuum distillation and drying of the oil coated particles. The ratio of oil to powder is 16% w/w. The oil coated powder is chilled with dry ice and then gently packed into a 1/4" O.D. teflon tube. Prior to service the new column is passivated by purging with 1% fluorine in nitrogen at 10 sccm for 12 hours. The temperature is held at  $120^\circ$  F during the passivation treatment.

The sample loop is formed by a multi-port teflon plug valve and interconnecting tubing. All wettable portions of the sample handling system are either teflon, nickel, or monel. Immediately after the sample loop, the carrier gas stream is split by using a nickel capillary restrictor (0.017" I.D. x 30" 1) and

teflon column (1/4" 0.D. x 2' 1) in one leg, and the natural restriction of the NaF-NaBr trap/converter (1/4" 0.D. x 18" 1) and teflon column (1/4" 0.D. x 30" 1) in the other leg. The capillary effects a 75/25 split of the carrier gas stream, 75% passing to the short column and 25% passing to the long column. As the gas streams elute from each column, they recombine before entering the gas density detector. The effluent from the system is stripped of fluorides in a solid sorbant chemical trap before venting to the atmosphere.

In order to measure UF $_6$  at the 20 PPM level, the major portion of the sample (75%) is routed to the short column where only the UF $_6$  is separated from the other components. All other components of this portion of the sample elute simultaneously and give rise to the peak identified as "composite" in the sample scans (Figure 10, Slide 8).

A dual amplifier recorder (Tracor Westronics, Model D11E; 0-5 and 0-10 mV ranges) is used to amplify and record the output from the detector. As shown in Figure 11, Slide 9, the 0-5 mV amplifier receives imput from an attenuated voltage divider which allows one-half strength signal (x2 attenuation) to pass. Although this allows the signals from other components in the sample to overwhelm the 0-5 mV amplifier, it does recover in time to respond correctly to the signal from any UF $_6$  in the sample. UF $_6$  in the concentration range of 10-20 PPM is readily measured with this system.

The second amplifier (0-10 mV) receives signal through a second voltage divider attenuator which is set to a less sensitive setting (x20 attenuation) to measure the signals from HF, CF<sub>4</sub>, and F<sub>2</sub> at concentrations of 0-1 mole %. The analyses of HF, F<sub>2</sub>, CF<sub>4</sub>, and UF<sub>6</sub> in the presence of air is normally quite complex and time consuming. The teflon columns required for corrosive halogen gases will resolve the lighter components (Br<sub>2</sub>, O<sub>2</sub>, HF, CF<sub>4</sub>, etc.) in approximately 10 minutes using a 30' column. However, if the column is sufficiently long to resolve the light components, the elution time of UF<sub>6</sub> becomes inordinately long (1-2 hours). For meaningful process control, the monitoring system must provide a complete analyses of all fluorides including UF<sub>6</sub> in 10-15 minutes. By using the chromatographic system described, these objectives are obtained. Three typical chromatograph scans are shown in Figure 11, Slide 13.

Table 1 shows comparative data from both field chromatograph analyses and laboratory titration analyses. Both methods yield reasonably comparative results. It should be noted that the laboratory titrations were from intermittant samples throughout the month. The chromatographic data is from continuous sampling throughout the same time period.

Table 2 shows the relative retention times for various gases on the teflon columns used in this study.

These adaptations of the corrosive gas chromatographs in the feed plant have resulted in improved control and efficiency and have provided excellent monitoring, records, and improved control of fluoride emissions.

Table 1
FLUORINATION PLANT VENT STACK ANALYSES

Date	Field Chromatograph Analyses (a)			Laboratory Titration Analyses (b)		
	UF <sub>6</sub> (PPM Molar)	F <sub>2</sub> (% Molar)	HF (% Molar)	UF <sub>6</sub> (PPM Molar)	F <sub>2</sub> (% Molar)	HF (% Molar)
Oct. 1976	37	0.8	1.40			
Nov. 1976	35	0.7	1.60			
Dec. 1976	36	0.7	1.56			
Jan. 1977	50	4.0	1.50			
Feb. 1977	100	5.4		100	4.4	1.6
Mar. 1977,	20	3.5		<100	3.9	
Apr. 1977 (c)	20	11.8		100	5.7	1.6
May 1977	20	7.1				
June 1977,,	23	7.8		and the second		
July 1977 <sup>(d)</sup>	250	3.3		300	4.2	
Aug. 1977				200	5.0	1.5
Sept. 1977	37	0.8	2.00	128	3.8	2.0

<sup>(</sup>a) Chromatographic data is average values from 875 analyses per month.


<sup>(</sup>b) Laboratory titration data is average values from 79 analyses per month.

<sup>(</sup>c) Began to process low assay and scrap materials in shut-down operations.

<sup>(</sup>d) Fluid bed absorber was not in operation during July, 1977.

Table 2
PERFORMANCE DATA FOR TEFLON COLUMN (a)

Gas	Retention Time(Sec.)	Sensitivity (mV/µMole)
02	320	• •
F <sub>2</sub>	320	0.3910
HF	400	
C1 <sub>2</sub>	500	0.4204
UF <sub>6</sub>	3960 (Long column)	
3	420 (Short column)	4.8872



PADUCAH FEED PLANT

Fig. 1






Figure 2




Figure



CORROSIVE GAS CHROMATOGRAPH FLOW SCHEME

Fig. 4



# GAS DENSITY DETECTOR

Fig. 5





Fig. 6




# LEGEND

B.C. = BEAN CENTER


--- F<sub>2</sub> ABSORBANCE

UF<sub>6</sub> ABSORBANCE





TELEDYNE F2 ANLYZER COMPONENT SYSTEM

Fig. 8



CORROSIVE GAS CHROMATOGRAPH FLOW SCHEME Fig. 9





#### REFERENCES

1. Harris, R. L., Mayo, T. J., Rossmassler, W. R., and Williamson, E. L.; Adaptation of The Chromatograph
For The Analysis of Corrosive Gases; 8th Conference on Analytical Chemistry in Nuclear Technology, Gatlinburg, Tennessee; October, 1964 (CONF 721-1)

#### **BIBLIOGRAPHY**

- 1. Ellis, J. F., Forrest, C. W., and Allen, P. L.; Analytical Chemica., Acta., 22, 27 (1960)
- 2. Iveson, G. and Hamlin, A. G.; Gas Chromatography Proceedings Symposium, 3rd., Edinburgh, Butterworths, London (1960)
- 3. Lysyj, I. and Newton, P. R.; Analytical Chemistry, 35, 90 (1963)

#### ACKNOWLEDGEMENTS

I would like to gratefully acknowledge the valuable assistance and encouragement of R. L. Harris, W. R. Rossmassler, and C. R. Beverly of the Technology Section and D. K. Riley, Operations General Supervisor, at the Paducah Gaseous Diffusion Plant in Paducah, Kentucky. This work was done at the Paducah Gaseous Diffusion Plant, Paducah, Kentucky, operated by Union Carbide Corporation for the Department of Energy under U. S. Government Contract W-7405 eng 26.

#### DISTRIBUTION

## Goodyear Atomic Plant

Crawford, J. G.

## Oak Ridge Gaseous Diffusion Plant

Weber, C. W.

### Oak Ridge Y-12 Plant

Griffin, J. D.

## Paducah Gaseous Diffusion Plant

Baker, R. C.
Beverly, C. R.
Bewley, H. D.
Carpenter, K. W.
Conrad, M. C.
Harris, R. L.
Hopkins. C. C.
Katzel, V. G.
Pulley, H.
Riley, D. K.
Tuholsky, A. M.

Walter, C. W. Library - KYRC

In addition, this report is distributed in accordance with the category UC-4, Chemistry, as given in the USDOE Standard Distribution Lists for Unclassified Scientific and Technical Reports, TID-4500-R66, September 1977.